


Technical Data

INJECTOR






• Main	0.91mm	- I 3+ (28-30/37)
		- I 3B/P (30)
	0.81mm	- I 3B/P (50)
• Rear Burner	1.00 mm	- I 3+ (28-30/37)
		- I 3B/P (30)
	0.90 mm	- I 3B/P (50)

INPUT

• Main	4 burner	14 kW	-937 grams / h
--------	----------	-------	----------------

DIMENSIONS




PE04R-BI-LP



WARNINGS INFORMATION

- **MINIMUM CLEARANCES FROM COMBUSTIBLE MATERIALS MUST BE:**
REAR - 450 mm
SIDES - 250 mm
TOP - 1000 mm




ASSEMBLY PE04R-BI-LP


Step 1: Install the Trim brackets .




Phillips Head Screw
1/4" X 3/8"
Qty. 4




Step 2: Install the grill onto the housing.




MOUNTING CUT - OUT



Step 3: Ignition Battery.



Step 4: Cooking Component Installation.



Part Diagrams and Lists-PE04R-BI-LP

